

Seashell SS-1
Lista kompatybilno ci
(Kwiecie 2010)

Firma	Modele aparatów							
Agfa Photo Optima	1	100	102	1338mT	1438m	2030m	2338mT	AP sensor 505-D
	DC733i	DC830i	DC733s	DC833m				
AIGO	F100	P1	T30	T35	T60	T1000	T1028	T1068
	T1200	T1258	T1260	V68	V80	V500	V630	V700
	V720	V728	V740	V760	V780	V800	V830	V860
	V866	V880	V890	V1000	V1018	V1080		
BENQ	C520	C530	C630	C740	C750	C840	C850	C1020
	C1060	C1220	C1230	C1250	C1255	E510	E520	E605
	E720	E800	E820	E1000	E1020	E1030	E1035	E1040
	E1050	E1050t	E1220	E1230	L1020	L1050	T700	T800
	T850	X600	X710	X720	X725	X835	W1220	
CANON	A200	A3000	A3100	IXUS30	IXUS40	IXUS50	IXUS55	IXUS60
	IXUS65	iXUS70	IXUS75	IXUS80	IXUS85IS	IXUS90IS	IXUS95	IXUS100IS
	IXUS105IS	IXUS110IS	IXUS120IS	IXUS130	IXUS200IS	IXUS400	IXUS430	IXUS500
	IXUS700	IXUS750	IXUS800IS	IXUS850IS	IXUS860IS	IXUS870IS	IXUS900TI	IXUS950IS
	IXUS960IS	IXUS970IS	IXUS980IS	IXUS990IS	IXY10	XY20IS	IXY25IS	IXY80IS
	IXY95IS	IXY110IS	IXY210IS	IXY220IS	IXY510IS	IXY810IS	IXY820IS	IXY830IS
	IXY910IS	IXY920IS	IXY2000IS	IXY3000IS	IXUS i5	IXUS i7	IXUS i7	IXY L4
	S85	S90	S400S410	S500	SD20SD40	SD100	SD200	SD300
	S400	S410	SD450	SD600	SD630	SD750	SD770	SD790
	SD800 IS	SD850	SD890	SD1100	IXUS i	IXUS IIs	IXUS II	IXUS Wireless
CASIO	FC100	FC150	S3	S5	S7	S10	S12	S100
	S500	S600	S770	S880	Z1	Z2	Z3	Z4
	Z5	Z6	Z7	Z8	Z9	Z10	Z11	Z19
	Z20	Z29	Z30	Z33	Z35	Z40	Z50	Z55
	Z57	Z60	Z65	Z70	Z75	Z77	Z80	Z85
	Z90	Z100	Z110	Z120	Z150	Z200	Z250	Z270
	Z280	Z300	Z330	Z400	Z450	Z500	Z550	Z600
	Z700	Z750	Z850	Z1000	Z1050	Z1080	Z1200	Z1200SR
COYOB	Savag-dc800							
FUJIFILM	A100	A150	A170	A175	A220	A225	A400	A500
	AV105	AX205	F10	F11	F20	F30	F31	F75
	F80	F85	F450	F455	F460	F470	F480	F70EXR
	F200EXR	F31fd	F40fd	F47fd	F50fd	F60fd	F100fd	F100pol
	J10	J20	J25	J26	J27	J30	J35	J50
	J100	J120	J250	JX200	JX255	JZ500	JZ505	J15fd
	J110W	J150W	V10	Z37				
GE	A735	A835	A950	A1050	A1200	A1230	A1235	A1250
	A1255	A1455	C1033	C1233	E840S	E850	E1050	E1055W
	E1240	E1250W	E1255W	E1480W	E1486TW	J1050	J1250	J1455
HAIER	A21	L90	L1080	MA5B	S40	S50	S52	S61
	T70	V80	V1080	V1082	V1280T	X80		
	C142	C180	C190	C763	C913	C1013	M320	M340

KODAK	M341	M380	M420	M550	M575	M580	M753	M763IS
	M853	M863IS	M872	M873	M883	M893 IS	M1033	M1063 IS
	M1073IS	M1093IS	M2008	V550	V603	V1073	V1273	V530 Zoom
	V550 Zoom	V750 Zoom						
LEICA	C-LUX 1	C-LUX 2	C-LUX 3					
NIKON	L2	L3	L6	L10	L11	L12	L14	L19
	L20	L22	S51C	S52C	S100	S200	S210	S220
	S230	S500	S510	S520	S550	S560	S570	S600
	S610	S620	S630	S640	S700	S710	S4000	S6000
OLYMPUS	CAMEDIA A74	FE20	FE26	FE46	FE47	FE130	FE140	FE150
	FE160	FE180	FE190	FE200	FE210	FE220	FE220D	FE230
	FE240	FE250	FE280	FE290	FE300	FE320	FE330	FE340
	FE350	FE360	FE370	FE3000	FE3010	FE4000	FE4010	FE4020
	FE4030	FE4040	FE5000	FE5010	FE5030	FE5500	FE5500	Mju700
	Mju710	Mju740	Mju750	Mju760	Mju780	Mju810	Mju820	Mju830
	Mju840	Mju1000	Mju1010	Mju1020	Mju1200	Mju1201	Mju1060	Mju5000
	Mju5010	Mju7000	Mju7010	Mju7030	Mju7040	Mju9000	SP700	X600
X905								
PANASONI C	FS1	FS2	FS3	FS5	FS6	FS7	FS12	FS15
	FS20	FS25	FS42	FS62	FX01	FX2	FX3	FX07
	FX7	FX8	FX9	FX10	FX12	FX30	FX33	FX35
	FX36	FX37	FX38	FX40	FX48	FX50	FX55	FX60
	FX100	FX150	FX180	FX500	FX520	FX550	FX580	LS5
	SV ME750	TZ6	ZS1					
PENTAX	A10	A20	A30	A36	A40	E40	E50	E60
	E65	E70L	H90	L36	M10	M20	M30	M40
	M50	M60	M70	M85	P70	S5i	S5n	S5z
	S4	S6	S7	S10	S12	S30	S40	S45
	S50	S55	S60	T20	T30	V10	V20	W20
	W60	W80	Svi					
POLAROID PREMIER	i737	i834	T830					
	DC67	DC68	DC87	DC593	DC6360	DC6370	DC6371	DM6365
	DM7362	DM7365	DS7450	DSA350	ES6	SL4	SL5	SL8
	SL53	SL58	SL63	SL68	SL83	SL86	SL1000	
RICOH	R1	R1V	R2	R2s	R3	R5	R6	R30
	R40	R50	RR730	RR750				
ROLLEI	Compactine9 0	Compactine10 1	Compactine110	Compactine200	da8	da70	da80	da81
	da100	da101	da120	da800	da1325	da6325	da7535	da8325
	da8535	dr135	dr835	Flexline140	Flexline200	XS10	X-8	
SAMSUNG	CL5	D75	D860	ES10	ES15	ES17	ES20	ES55
	ES60	ES70	IT100	M310	L60	L70	L73	L77
	L100	L110	L201	L210	L301	L310W	L700	L730
	L830	NV8	NV15	NV20	NV24HD	NV30	NV40	NV100HD
	NV103	NV106HD	PL50	PL51	PL55	PL60	PL65	PL70
	PL150	PL502	S85	S500	S600	S630	S730	S750
	S760	S830	S1030	S1070	SL102	SL202	SL620	SL720
	SL820	ST45	ST500	ST550	TL100	TL220	TL225	TL320
WB100	WB1000							
SANYO	E7	E10	E760	E1000	E1090	S6	S7	S870

SANTO	S880	S1070	S1080	S1275	T700	T1060	X1250	
SONY	N1	N2	S650	S700	S730	S780	S930	S950
	S980	WX1	W30	W35	W50	W55	W70	W80
	W90	W100	W110	W120	W130	W150	W180	W190
	W200	W210	W230	W270	W290	W300	W310	W320
	W350	W380	W390					
YASHICA	EZF524	EZF525	EZF531	EZF725	EZF824	EZF924	EZF1027	EZF1231
	EZF1233	EZ8032	EZF8321					